

Universalrem for artiststylter

20472-25

Remmen er 70 cm lang, og bruges til hæl og tå til alle Actoy stylter.

Har du behov for at justere remmens længde, kan du klippe i en vinkel på ca. 45 grader. Brænd den afklippede kant med en lighter i ca. 1-2 sekunder for at undgå at remmen trevler.

The strap is 70 cm long, and is used for heel and toe for all Actoy stilts.

If you need to adjust the length of the strap, you can cut at an angle of approx. 45 degrees. Burn the clipped edge with a lighter for 1-2 seconds to avoid the belt fraying

